

CARE AND OPERATING INSTRUCTIONS FOR

PONDMASTER®

&

Supreme®

By Danner Manufacturing, Inc.

AIR PUMPS

Models AP-20, AP-40,
AP-60 AND AP-100

**SAVE THESE
INSTRUCTIONS**

| MODEL | SUPREME ITEM # | PONDMASTER ITEM # |
|--------|-------------------|----------------------|
| AP-20 | 04220 | 04520 |
| AP-40 | 04240 | 04540 |
| AP-60 | 04260 | 04560 |
| AP-100 | 04280 | 04580 |

FOR POND AND AQUARIUM APPLICATIONS

The Supreme AP-Series air pumps have been designed to satisfy the requirements of a multitude of water related applications. These beautifully designed, environmentally friendly pumps can be used for:

- Oxygenating Outdoor Ponds and Water Gardens
- De-Icing Outdoor Installations During Harsh Winters
- Oxygenating Indoor Water Features
- Aerating Single or Multiple Aquarium Tanks
- Aerating single or Multiple Terrarium Tanks

All AP-Series air pumps operate on standard 110V electric and come with 6' power cords. They have been designed to operate efficiently with a motor that is non-oil lubricated. For outdoor applications, it is recommended that the water-resistant ABS plastic unit be enclosed with allowance for air circulation to protect it from the elements.

INSTALLATION INSTRUCTIONS - AQUARIUM:


1. Connect one end of the short length of included hose to the outlet on the pump and fasten with the included hose clamp.
2. Connect the supplied barbed diffuser to the other end of the hose and fasten with the included hose clamp.
3. Run a length of airline hose from each of the outlet barbs on the diffuser to airstones in the aquarium(s).
4. If the air flow is too great, purchase and install an adjustable flow valve for each affected airline. Allow excess air to bleed off by attaching an adjustable flow valve to an unused outlet on the diffuser. Do not totally restrict the flow with the valve.



AP-40 with an added hose section and included air diffuser



AP-40 with included air diffuser and short hose section



AP-100 Shown with added hose and included diffuser

INSTALLATION INSTRUCTIONS - POND APPLICATIONS:

CAUTION: PONDS CAN BE DANGEROUS TO SMALL CHILDREN. NEVER LEAVE CHILDREN UNSUPERVISED NEAR A POND!

1. Connect one end of a length of hose to the outlet on the pump. Hose length is the distance from the permanent location of the pump to the water's edge plus the depth of the water. (NOTE: A short section of hose and 2 clamps are included in this package. These parts are for aquarium installations and can be disregarded for pond use.)
2. Connect the supplied barbed diffuser to the other end of the hose.
3. The diffuser needs to be weighted since it is very buoyant when filled with air. Attach the diffuser and about 4" of hose to a heavy object, such as a brick or rock, with a cable tie. (Do not use a weight that will rust or leach toxic substances.)
4. Locate pump in a protected area. It should be covered to shelter it from rain and the elements. Be sure to allow for ventilation. Locate pump so that it cannot fall into the water.


| PUMP MODEL | HOSE I.D. |
|---------------|--------------|
| AP-20 | 1/2" |
| AP-40 | 5/8" |
| AP-60 | 3/4" |
| AP-100 | 3/4" |

NOTE: In winter, damp air can condense onto the inside wall and freeze the hose. This can eventually block the hose completely, therefore it is important to check frequently during periods of freezing temperatures.

SERVICE AND MAINTENANCE

There are no parts that need lubrication. The integrated air filter requires periodic cleaning. See photo for proper procedure. To clean the filter media, remove the air filter cover. Extract the filter media from the pump and rinse thoroughly with cold water. Replace media into the empty filter cavity, replace the air filter cover and refasten. When the airflow slows down, it is time to replace the diaphragms and flapper valves. A complete replacement kit is available (see parts list, below). There are two of each (diaphragms, flapper valves), one at either end of the pump.

1. Disconnect the pump from the AC receptacle.
2. Remove the cover lid.
3. Unscrew the diaphragm / flapper combination assembly from either end of the pump and separate the two parts.
4. Remove the flapper valves and replace with the supplied parts. Be sure to maintain the same orientation of the flapper valves.
5. Remove the black, round doughnut-like diaphragm and replace with the supplied parts.
6. Replace the diaphragm / flapper assembly and refasten.
7. Replace the cover lid.



CAUTIONS

WARNING: FOR YOUR PROTECTION, ALWAYS UNPLUG THE UNIT FROM ITS POWER SOURCE BEFORE INSTALLING OR SERVICING. SHOULD THE UNIT APPEAR TO BE NOT WORKING, DO NOT ATTEMPT TO REACH, REMOVE, OR DISASSEMBLE BEFORE DISCONNECTING FROM THE POWER SOURCE.

1. This pump is solely intended to pump air. Do not use for oil, solvents, or any petroleum products (gasoline, diesel, etc.).
2. ALWAYS use a properly grounded AC outlet. Do not immerse the pump's plug in water or attempt to plug in a wet plug.
3. Provide a "drip loop" for the line cord. This is a loop in the cord below the level of the receptacle or plug that prevents water from traveling along the cord in the direction of the receptacle.
4. Be sure that a ground fault circuit interrupter (GFCI) is installed in the branch circuit supplying the aquarium, fountain, or pond equipment.
5. NEVER remove the ground pin from the plug.

LIMITED ONE-YEAR WARRANTY

E.G. Danner Manufacturing, Inc. will repair or replace any air pump found to be defective within one year of original purchase. Air filter, flapper valves, and diaphragms are wearable items and are not covered by this warranty. Cutting or altering the cord voids any warranty consideration. For warranty repair, return only the part that is defective to our factory. Please include a dated proof of purchase and \$10.00 for postage and handling. Damages or injuries resulting from negligence or misuse of the product are not covered by this warranty. This warranty gives you specific legal rights. You may have other rights which may vary from state to state.

| Model | For Ponds up to: | Maximum Water Depth | Air Flow Inches ³ /Min | Power | Hose Size Usage |
|--------|------------------|---------------------|-----------------------------------|-----------|-----------------|
| AP-20 | 2500 Gallons | 7 Feet | 1700 | 20 Watts | 1/2" ID |
| AP-40 | 5000 Gallons | 10 Feet | 2900 | 40 Watts | 5/8" ID |
| AP-60 | 7000 Gallons | 9.6 Feet | 5500 | 50 Watts | 3/4" ID |
| AP-100 | 10,000 Gallons | 11.5 Feet | 9150 | 100 Watts | 3/4" ID |

SPARE PARTS FOR SERIES AP PUMPS

| Model | AIR DIFFUSER | DIAPHRAGM KIT | TUBING |
|--------|--------------|---------------|------------------------|
| AP-20 | Item #14505 | Item #14525 | 1/2" x 10' Item #12012 |
| AP-40 | Item #14515 | Item #14545 | 5/8" x 20' Item #12158 |
| AP-60 | Item #14550 | Item #14555 | 3/4" x 50' Item #12035 |
| AP-100 | Item #14560 | Item #14565 | 3/4" x 50' Item #12035 |

01/09 ZG143

CAUTION: PONDS CAN BE DANGEROUS TO SMALL CHILDREN. NEVER LEAVE CHILDREN UNSUPERVISED NEAR A POND!

DANNER MFG. INC. • 160 Oval Drive, Islandia, NY 11749-1489 • Visit our web site at www.Dannermfg.com • Made in China